

909463 001 Page 1 of 24

(incorporated in South Australia)

### BEACH PETROLEUM N.L.

DRILLING PROGRAM

WESTGATE NO. 1 07 FEB 1986

OIL and GAS DIVISION

#### BEACH PETROLEUM N.L.

#### WESTGATE -1

#### DRILLING PROGRAM

909463 603

#### CONTENTS

#### A. GENERAL

- 1. Rig Location
- 2. Target Locations
- 3. Wellbore Path
- 4. Reason for Drilling
- 5. Geological Prognosis
- 6. Contractor and Rig
- 7. Remarks
- 8. Approvals

#### B. PROGRAM

- 1. Summary Drilling Program
- 2. Bit Program
- 3. Hydraulic Program
- 4. Deviation Requirements
- 5. Mud Program
- 6. Casing and Cementing Program
- 7. Formation Sampling
- 8. Logging Program
- 9. Testing Program

#### **FIGURES**

Table 1 - Casing and Cementing Program

Location Map

Structure Map - Top Pebble Point Formation

#### APPENDIX

Drill Site Location Plan Rig Specifications

#### DRILLING PROGRAM

#### WESTGATE -1

909463 004

#### A. GENERAL

#### 1. RIG LOCATION (Surface)

Latitude: 38° 27' 58'' S

Longitude: 142° 53' E

Elevation: GL:88.0 m ASL


KB:94.0 m ASL

#### 2. TARGET ELEVATIONS

Two targets are programmed for this well, one in the Pebble Point Formation and one in the Waarre Formation. Both targets are circles of radius 100 m and 50 m respectively with their centres referenced as follows:

**	Pebble Point	Waarre	
Shot Point:	172	185	
Seismic Line:	TME 400	TME 400	
Latitude:	38° 27' 53" S	38° 27' 44" S	
Longitude:	142° 53' 18" E	142° 53' 28" E	
Depth, m TVD KB:	789.0	1554.0	
Bearing from Rig:	37° 30'	37° 30'	
Distance from Rig (Horizontal):	180 m	570 m	

Both targets have <a href="hard-boundaries">hard-boundaries</a> all round.



#### 3. WELLBORE PATH

Total Depth:

1654 m TVD (1817 m AHD)

Average Angle:

27° 00'

Kick-Off-Point:

125 m


#### 4. REASON FOR DRILLING

The proposed well will primarily test the hydrocarbon potential of the basal Tertiary Pebble Point Formation and the basal Upper Cretaceous Waarre Formation.

Westgate No. 1 is located within a fault dissected platform that separates two major faults. The prospect is a seismically defined horst block, with the Waarre and Pebble Point plays formed by a prominent down to the north east normal fault.

The Westgate horst block is an asymmetric structure causing the Pebble Point Formation high points to be offset laterally by 390 m, with the Waarre high lying to the north east. To intersect both primary targets at their crest the well bore requires a deviation of approximately 27° from the vertical throughout the Upper Cretaceous Formation.

Hydrocarbon prospectivity is potentially good. Oil fluorescence has been noted in the Pebble Point Formation at Timboon No. 5, 7.5 km east south east. In addition the Westgate No. 1 prospect is in the same geological province that contains the North Paaratte gas fields and the Port Campbell No. 4 oil recovery.



#### 5. GEOLOGICAL PROGNOSIS

	Depth Below	Depth Below
Stratigraphic Unit	KB TVD	KB AHD
	(m)	(m)
Port Campbell Limestone	Surface	Surface
Gellibrand Marl	168	171
Clifton Formation	388	398
Narrawaturk Formation	408	419
Mepunga Formation	444	459
Dilwyn Formation	499	521
Pember Mudstone	755	808
Pebble Point Formation	789	846
Paaratte Formation	824	886
Skull Creek Mudstone	1289	1408
Nullawarre Greensand	1352	1479
Belfast Mudstone	1494	1638
Flaxmans Formation	1504	1649
Waarre Formation	1554	1705
Otway Group	1582	1736
T.D	1654	1817

#### 6. CONTRACTOR AND RIG

Richter - Rig 8.

#### 7. REMARKS

Unless otherwise stated all depths in this program are relative to the kelly bushing (RKB) and all bearings are relative to true north (azimuth).

for the attention of

JOHN MORGANS

GARY SCOTT

Please find enclosed copies of the "approvals page" (d) ly signed for the WESTGATE 1 well program | 17 FEB 1986

with compliments of

BEACH PETROLEUM NO LIABILITY

4TH FLOOR, 685 BURKE ROAD, CAMBERWELL, VICTORIA, 3124 (P.O. BOX 360, CAMBERWELL, VICTORIA, 3124) TELEPHONE: (03) 813 3311 TELEX: AA36500, FAX: (03) 813 3902

### 8. APPROVALS

EXECUTIVE DIRECTOR

**EXPLORATION DIRECTOR** 

OPERATTONS MANAGER

8. APPROVALS

EXECUTIVE DIRECTOR

EXPLORATION DIRECTOR

OPERATIONS MANAGER

#### B. PROGRAM

#### 1. SUMMARY DRILLING PROGRAM

- 1.1 20" conductor will be set to 9.0m (approx.) during location preparation.
- 1.2 Use a  $12\frac{1}{3}$ " drilling assembly to drill to the KOP at approximately 125m. At this point POOH and pick up a dyna-drill with  $2\frac{1}{2}^{\circ}$  bent sub. Orient the dyna-drill and kick off the well using a build rate of around  $2\frac{1}{2}^{\circ}/30m$ . Once an inclination of approximately 15° has been achieved, pull the dyna-drill and RIH with a building assembly. Build angle until the average angle of 27° has been obtained or until sufficient angle is available to penetrate both targets. Based on the proposed well path, this should occur at approx. 453m AHD (441m TVD). Surface casing should be set at this depth, although the actual depth will be determined on site once the casing has been measured so as to provide 3m of hole below the casing shoe.

Progress should be closely monitored against the directional company's proposed well path and the directional program adjusted as needed in consultation with the Operations Manager.

- 1.3 Strap out of hole to the  $6\frac{1}{4}$ " DC's to check pipe tally.
- 1.4 RIH with  $12\frac{1}{4}$ " bit to T.D.
- 1.5 Circulate and clean hole.
- 1.6 POH to run  $9^5/8$ " casing.

- 1.7 Run 9<sup>5</sup>/8" casing complete with float shoe, float collar (on top of first joint) and 5 centralisers on 5 lower joints. Tack weld bottom of collar on shoe joint. Make-up float shoe and all connections between shoe joint and one above with threadlocking compound. Fill casing every 2 3 joints as it is run in the hole. Chain down casing prior to cementing.
- Cement casing to surface using top plug only as per Table
   Bump cement plug and pressure test casing to 1000 psi. Check float valves are holding, if okay bleed off.
   Do not leave slips in rotary table. Collect 2 samples per mix of cement and store in a dry warm place.
- 1.9 If samples are hard after 8 hours, slack-off travelling block.
- 1.10 Backoff landing joint. Install casing head and BOP's and pressure test to 1000 psi against cup type test plug.
- 1.11 Pressure test all valves in the choke manifold to 100 psi.
- 1.12 RIH with a long tooth soft formation 8½" bit, drill out cement plugs, shoe track and approx. 5m of new hole.
- 1.13 Carry out Pressure Integrity Test using cementing pump, taking care to shut down pumps once the PIT limit has been established.
- 1.14 Drill  $8\frac{1}{2}$ " hole to T.D. at 1820 AHD (1654m TVD).
- 1.15 Electric log and evaluate the well as necessary. Run velocity survey.
- 1.16 Complete or abandon the well as the case may be.

Note:  $5\frac{1}{2}$ " cased hole APR testing equipment will be available.

#### 2. BIT PROGRAM

<u>Hole</u>	<u>Interval</u>	Metres	Anticipated	Bits to
Size	m AHD		Usage	be Avail.
30"	GL-9	3	Back hole &	
			auger dig.	
			`	
12½"	9-453	444	1 x L3A	1 x L3A*
			1 x 5335	2 x 5335
81211	444-1820	1376	1 x 5335	1 x 5335
			2 x S44G	3 x S44G
			1 x 582F	2 x 582F

<sup>\*</sup> Denotes already in Cobden stock.

#### 3. HYDRAULIC PROGRAM

#### 3.1 12½" Hole

Spud in and drill the first  $30\,\mathrm{m}$  of hole with circulation rates of 300 -  $350~\mathrm{gpm}$ .

Use jets and flow rates as determined by dyna-drill hydraulic requirements. Maintain sufficiently high circulation rates to ensure good hole cleaning.

#### 3.2 $8\frac{1}{2}$ Hole

Jet sizes should be chosen to optimise bit hydraulics whilst maintaining circulation rates of the order of 250 - 300 gpm. In general 10/32 jets should be used.

#### 4. DEVIATION AND BOTTOM HOLE ASSEMBLIES

#### 4.1 12½" Hole

While dyna-drilling, take surveys after every connection until it is evident that the well is building angle at the required rate and the well path is predictable. Thereafter run surveys as required.

A building assembly will be run following the dyna-drill and surveys should be made after every 30m until its behaviour is established when surveys may again be taken as required.

Consult with Directional Company for recommended BHA configurations.

#### 4.2 8½" Hole

Drill out the surface casing with a holding assembly taking surveys as required to ensure the well is maintaining course. However, do not exceed a coarse length of 150 m between surveys.

Consult with Directional Company for recommended BHA configurations.

#### 5. MUD PROGRAM

See Mud Engineering companies recommendations for further details.

<u>Hole</u>					•
Size	<u>Interval</u>	Wt. ppg	Vis. Sec.	W.L. cc	Notes
12 <sup>ነ</sup> ረ"	8-453	8.6	35	N.C.	Water plus visc, slugs.
81211	453-1820	9.2-9.5	40 - 45	8 - 12	KCL/polymer

#### Note:

- (a) A lightly treated non-dispersed mud system containing 10 lb/bbl of KCL will reduce the likelihood of mud ring problems occurring.
- (b) Drilling Detergent should be available to eliminate bit balling if required.
- (c) Stuck pipe spotting fluid will be available on site.

Full mud checks will be performed twice daily under normal circumstances by the mud engineer.

Running checks of mud weight and viscosity in and out will be performed by the rig crew every  $\frac{1}{2}$  hour whilst circulating. A routine check will be taken twice each tour.

A formation leak off test will be taken after drilling 5m of new hole below the  $9^5/8"$  casing shoe.

#### 6. CASING AND CEMENTING PROGRAM

Refer Table 1 attached.

#### 7. FORMATIONS SAMPLING

#### 7.1 Cuttings

Shaker samples will be taken at 10m intervals to approx. 510m (top of Dilwyn), and thereafter at 3m intervals to T.D. These samples are to be washed and dried and stored in labelled polythene bags. Four sets are required. In addition a fifth set of samples, unwashed and air dried will be collected from 510m to T.D. This set is to be compounded over 9m intervals by combining 3 sets of 3m interval samples.

#### 7.2 Cores

Conventional cores will not be cut in this well. Sidewall cores will be taken after logging for formation evaluation and for palynological purposes.

#### 8. LOGGING PROGRAM

Logs run prior to the setting of the  $9^5/8$ " casing:

(i) ISF - SLS - 454m AHD to conductor pipe.

At T.D. the following Schlumberger logs will be run:

- (i) DLL MSFL T.D. to  $9^5/8$ " casing.
- (ii) SLS T.D. to  $9^5/8$ " casing.
- (iii) LDL CNL T.D. over zones of importance.
- (iv) SHDT T.D. over zones of importance.
- (v) CST 30 shots.
- (vi) WSS 20 levels.

In the event that significant hydrocarbons from logs are encountered it may be that after discussion with Bridge Oil, other logs may be run.

#### 9. TESTING PROGRAM

In the event of significant hydrocarbon shows, it may be decided to conduct a drill stem test. Any decision in this regard will be made after consultation with Bridge Oil.

All testing will be conducted using Annular Response Tools. A recommended running procedure and program will be issued in the event a test is called.

	CEMENT & ADDITIVE	25sxs construction cement.	340sxs A.B. Class A cement with 2%	prenydrated bentonite followed by 160sxs A.B. Class A cement neat.	150sxs A.B. Class A cement with 2% prehydrated	bentonite 0.4% HR-7 followed by 250sxs A.B. Class A. cement neat with 1.0% CFR-2 and 0.2% HR12.
	CEMENTED TO	Surface	Surface			
SAFETY FACTORS	TENSION	щ	н		1.9	
SAFETY	BURST	н	н		1.4	
	COLLAPSE	H			1.2	
	GRADE	Conductor	J55 STC		J55 STC	v
	WEIGHT (1bs/ft)		36		17	
	DEPTH (mAHD)	6-0	0-454	· .	0-1820	
	HOLE SIZE (INS)	30	$12^3$		1%	
	CASING SIZE (INS)	20	8/56		5,2	

CASING AND CEMENTING PROGRAM

NOTES:

The shoe joint and four above will be centralized. A 20bbl water pre flush will be used on all jobs (a) (P)

Top and bottom cement plugs will be used.

(c)

The  $5\frac{1}{2}$ " casing will be centralized through all hydrocarbon bearing intervals. Pressure on the  $9^5/8$ " 36 lb/ft J55 casing must not exceed 2000 psi. (P)

(e) (f)

A.B. = Adelaide Brighton.

# ASSUME:

 $\overline{9}.2$  ppg mud behind  $9^5/8$ " casing, 10.00 ppg mud behind  $5\frac{1}{2}$ " casing. Normal formation pressure of gas sands 0.44 psi/ft. (a)

Gas gravity 0.6. (a)

RICHTER DRILLING PTY. LTD.


RIG 8

DRILL SITE LOCATION PLAN

RICHTER DRILLTING PTY LTD.

RIG 8

DRILL SITE LOCATION PLAN



SCALE 1:750
NOTE: ALL MEASUREMENTS IN METRES (AREA MUST BE LEVEL)

RICHTER DRILLING PTY. LTD.

NATIONAL 80B - RIG NO. 8

RIG SPECIFICATIONS

#### RICHTER DRILLING PTY. LTD.

909463 021

#### MATIONAL 80B - RIG NO. 8

**DRAWWORKS** 

National 80B, 1-1/4" Drill Line. National type B1 Catheads, Parmac Hydromatic brake, driven off compound.

**POWER** 

3 each Superior PTDS6, each rated at 600 HP at 900 RPM.

COMPOUND

National B24, 3 Section.

MUD PUMPS

2 each National 9-P-100 Triplex 1000 HP 6-3/4" X 9-1/4" equipped with 6-1/4" liners and pistons with hydril K20-5000 pulsation dampeners. Both with independent drive - CAT D399TA industrial engines.

MAST

Lee C. Moore, 142 ft. 860000 lbs. capacity. 1 x 60" - 5 x 48" sheaves in crown.

SUBSTRUCTURE

Main substructure 10' 6" high, plus pony substructure 11 ft. high for total height of 20'6".

Motor substructure, total height 12' high composed of three subs, 5' plus 4'9".

MATTING .

1 set sectionilized hardwood matting.

ROTARY TABLE

National C275, 27-1/2".

HOOK BLOCK

National Type G, 350 ton.

SWIVEL

Ideal RB3

KELLY DRIVE

Baash Ross, Type 2 RCH 6.

MUD AGITATORS

2 "Lightnin" Mixers. 2 Brandt MA 7.5

**MUD TANKS** 

Shaker 37' x 8' x 4'6" Intermediate tank 34 x 8 x 5 Suction tank 37 x 8 x 5750 BBL capacity

SHALE SHAKER

Brandt Dual Tandem

DEGASSER

Drilco Standard Pit

DESANDER

Demco 4 cone, with BJ 5" x 6" pump

DESILTER

Pioneer 12 x 4" Cones, with pump

GENERATING PLANT

2 Cat D3408 Generator sets

CHOKE MANIFOLD

3" x 5000 psi wt 2" H2 chokes

BOP'S & ACCUMULATOR

Annular, Stamco 13-5/8" 5000 psi

. 2 - Cameron 13-5/8 x 5000 psi U Type

Accumulator, koomey 35120-35, 12 bottles

Hydril 10000 psi Upper Kelly Cock Gray inside BOP, 4-1/2" XH

Hydril Lower Kelly Cock

DRILLING RECORDER

Martin Decker 6 pen

Pit Volume/Automatic Driller/Flo Sho/Stroke

Counter/Rotary RPM/Rotary Torque

RIG LIGHTING

Hutchinson system of 48" double tube fixtures

COMPRESSORS

1 x Atlas Copco BT4 (on compound)

Sullair Rotary Compressor (elec driven)

WELDING AND CUTTING

Lincoln model 400AS electric welding machine

Oxy and acetylene cutting equipment

MUD LAB

Baroid model 821

DEVIATION SURVEY

Totco unit No. 6, 8° double recorder

KELLY

5-1/4" Hex, 4-1/2" IF Pin, 40 ft long, 37 ft

working space.

DRILL PIPE

10000 ft 4-1/2" OD, 20 lb/ft, Grade E, Range 2

15 joints heavy wate drill pipe 42 lb/ft

PUP JOINTS

 $1 \times 5' - 1 \times 10' - 1 \times 20'$  Gr "G" 4-1/2" OD

DRILL COLLARS

12 x 8" OD, 6-5/8" API Reg 24 x 6-1/4" OD, 4-1/2" XH

HANDLING TOOLS

Power tongs, Farr 13-3/8
Jaws for 7", 9-5/8" and 13-3/8"
Varco SSW10 Spinning Wrench

**TONGS** 

BJ type B with lug jaws, 3-1/2" to 13-3/8" BJ type SDD with jaws for 8-1/2" to 12" BJ/Wilson for 20" casing

**ELEVATORS** 

BJ type BB 275 ton for 4-1/2 DP Elevators and single joint elevators for:

5-1/2" casing 7" casing 9-5/8" casing 13-3/8" casing 20" casing

Varco type HS spider for 20" casing

SLIPS

- . Varco SDML slips for 3-1/2" & 4-1/2" Drill Pipe
- . Drill collar slips, DCS-R
- . Casing slips, CMXL

FISHING TOOLS

Bowen model 150 overshots

- . 11-3/4" OD, FS
- . 9-5/8" OD, FS
- . 8-1/8" OD, FS

Bowen type Z hydraulic jars, 6-1/4" OD

Bowen reverse circ junk basket, 8-1/8" OD

- 1 Junk Sub for 8-1/2" hole
- 1 Junk Sub for 12-1/4" hole
- 1 Bowen magnet 7" OD #32300

**GENERATOR HOUSE** 

40' x 10' x 9'

- 4

MECHANICS WORKSHOP

36' x 8'6" x 9'

FUEL TANK

6000 gallons, skid mounted

909463 024

WATER TANK

400 barrel

WATER PUMP

Southern Cross 2 x 1-1/2" powered by Petters diesel

JUNK BOX

21' x 7' x 6'4"

TOOL HOUSE

27' x 9' x 9'

**DOGHOUSE** 

26' x 9' x 9'

**TRANSPORT** 

1 Oilfield rig truck

1 Toyota Landcruiser Utility 4WD

1 Toyota Landcruiser Wagon - 4WD (11 seater)

1 Clark 504 Forklift

CAMP

3 - 40' x 10' 10 man air-conditioned accommodation units

1 - 40' x 10' kitchen unit with freezer and cold unit

1 - 40' x 10' diner unit

 $1 - 40' \times 10'$  ablution unit

1 - 40' x 10' canteen unit

All skid mounted