

Well : BASKER FFD

NOTE: Other sheets use this START DATE & TIME & POB Information in their setup

Starting POB : 83
 Max POB on rig : 100
 Start Date & Time : Sat 25-Feb-06 8:00
 Forecast End Time : Mon 12-Jun-06 7:30

| Start Time | Description | Target | Actual | Comments |
|------------------|--|------------|------------|-----------------------------|
| 08:00 Sat 25 Feb | Conductor and Surface casing setting operations | 288.00 hrs | 253.50 hrs | |
| 21:30 Tue 07 Mar | Basker 5 12.25in hole section | 432.00 hrs | 622.50 hrs | |
| 20:00 Sun 02 Apr | Basker 3 12.25in hole section | 450.00 hrs | 516.50 hrs | 2 hrs NPT Blue pod tugger |
| 08:30 Mon 24 Apr | MU 8-1/2" BHA, RIH, drill out shoe track and conduct FIT | 18.00 hrs | 19.00 hrs | |
| 03:30 Tue 25 Apr | Drill 8-1/2" hole from 3530m to TD at 4125m (12m/hr) | 50.00 hrs | 59.00 hrs | |
| 14:30 Thu 27 Apr | POH | 10.00 hrs | 15.00 hrs | |
| 05:30 Fri 28 Apr | Rig up and make 3 wireline evaluation runs | 48.00 hrs | 46.00 hrs | |
| 03:30 Sun 30 Apr | RIH. Wiper trip. Condition Hole. | 0.00 hrs | 0.00 hrs | no wiper trip time allowed |
| 03:30 Sun 30 Apr | Run and cement 7" liner | 40.00 hrs | 44.50 hrs | |
| 00:00 Tue 02 May | Run VSP | 12.00 hrs | 14.50 hrs | |
| 14:30 Tue 02 May | Suspend. Set storm packer in 9-5/8" casing | 4.00 hrs | 2.50 hrs | |
| 17:00 Tue 02 May | Release BOP. Release guide wires | 2.00 hrs | 2.00 hrs | Shut in production Basker 2 |
| 19:00 Tue 02 May | Position rig over Basker 4 | 2.00 hrs | 2.50 hrs | |
| 21:30 Tue 02 May | Install guide wires. Latch BOP | 2.00 hrs | 3.00 hrs | |
| 00:30 Wed 03 May | L/D 8" DC'S and Jar; MU 9-5/8" csg running tool and rack b ack | 2.00 hrs | 1.50 hrs | |
| 02:00 Wed 03 May | M/U 12 1/4" BHA and RIH | 6.00 hrs | 6.00 hrs | |
| 08:00 Wed 03 May | Full BOP Test | 8.00 hrs | 10.50 hrs | |
| 18:30 Wed 03 May | RIH and drill out casing. Perform LOT, slip and cut | 4.00 hrs | 11.50 hrs | |
| 06:00 Thu 04 May | Drill 12-1/4" hole fm 1112m to 1178m | 6.00 hrs | 6.00 hrs | |
| 12:00 Thu 04 May | Round trip to replace failed Geopilot | 0.00 hrs | 17.00 hrs | Failed Geopilot (again) |
| 05:00 Fri 05 May | Drill 12-1/4" hole fm 1178m to circa 2600m (20m/hr) | 64.00 hrs | 64.50 hrs | |
| 21:30 Sun 07 May | Round trip for new bit and pick up Geopilot | 24.00 hrs | | |
| 21:30 Mon 08 May | Drill 12 1/4" Hole fm 2600m to TD at 3350m (10m / hr) | 75.00 hrs | | |
| 00:30 Fri 12 May | Condition Hole. POOH. | 12.00 hrs | | |
| 12:30 Fri 12 May | Rig up and make 3 wireline evaluation runs | 50.00 hrs | | |
| 14:30 Sun 14 May | RIH. Wiper trip. Condition Hole. | 0.00 hrs | | no wiper trip time allowed |
| 14:30 Sun 14 May | Run 9 5/8" casing. | 24.00 hrs | | |
| 14:30 Mon 15 May | Cement 9-5/8" casing | 6.00 hrs | | |
| 20:30 Mon 15 May | Pressure test BOPs & casing on Basker-4 | 8.00 hrs | | |
| 04:30 Tue 16 May | Run Well Patroller to PBTD (≈ 3570m) to clean up well, circulate to inhibited brine & HiVis pills, clean up BOP and wellhead, POOH | 30.00 hrs | | |
| 10:30 Wed 17 May | Rig up Schlumberger electricline, run CBL/VDL/GR/CCL Log | 5.00 hrs | | |
| 15:30 Wed 17 May | RIH and perforate reqd intervals overbalanced (assume 3 runs), r/d | 12.00 hrs | | |
| 03:30 Thu 18 May | Pull wear bushing, jet clean wellhead again | 4.00 hrs | | |
| 07:30 Thu 18 May | Rig up tubular handling equipment | 1.00 hrs | | |
| 08:30 Thu 18 May | Determine tubing hanger spaceout with Lead Impression Tool on completion riser (~15 jts / assys), rack back riser | 4.00 hrs | | |
| 12:30 Thu 18 May | Run tailpipe, packer and 4 1/2" completion string (~240 jts / assys) | 24.00 hrs | | |
| 12:30 Fri 19 May | M/u SSSV, run remaining 4 1/2" completion (~6 jts / assys, 1 x C-L) | 3.00 hrs | | |
| 15:30 Fri 19 May | M/u & run tubing hanger with 5 1/2" completion riser, space out | 10.00 hrs | | |
| 01:30 Sat 20 May | R/u & test slickline, FOBV and surface lines, land & test hanger | 3.00 hrs | | |
| 04:30 Sat 20 May | Pressure up on FBIV & set packer, test tubing & annulus | 2.00 hrs | | |
| 06:30 Sat 20 May | Perform inflow test on SSSV. Slickline set & test ARH plug & prong in tubing hanger, r/d slickline | 3.00 hrs | | |
| 09:30 Sat 20 May | Unlatch THRT, POOH & stand back landing string | 8.00 hrs | | |
| 17:30 Sat 20 May | Install new AX Gasket on Basker-5 wellhead, unlatch BOP and guidelines off Basker-4, move rig over Basker-5, install guidelines, land and latch BOPs. Install debris cap on Basker-4 wellhead. | 6.00 hrs | | Shut in production Basker 2 |
| 23:30 Sat 20 May | Pressure test BOPs & casing on Basker-5 | 8.00 hrs | | |
| 07:30 Sun 21 May | Run Well Patroller to PBTD (≈ 3560m) to clean up well, circulate to inhibited brine & HiVis pills, clean up BOP and wellhead, POOH | 30.00 hrs | | |
| 13:30 Mon 22 May | Rig up Schlumberger electricline, run CBL/VDL/GR/CCL Log | 5.00 hrs | | |
| 18:30 Mon 22 May | RIH and perforate reqd intervals overbalanced (assume 3 runs), r/d | 12.00 hrs | | |
| 06:30 Tue 23 May | Pull wear bushing, jet clean wellhead again | 4.00 hrs | | |
| 10:30 Tue 23 May | Rig up tubular handling equipment | 1.00 hrs | | |
| 11:30 Tue 23 May | Determine tubing hanger spaceout with Lead Impression Tool on DP | 3.00 hrs | | |
| 14:30 Tue 23 May | Run tailpipe, packer and 4 1/2" completion string (~240 jts / assys) | 24.00 hrs | | |
| 14:30 Wed 24 May | M/u SSSV, run remaining 4 1/2" completion (~6 jts / assys, 4 x C-L) | 3.00 hrs | | |
| 17:30 Wed 24 May | M/u & run tubing hanger with 5 1/2" completion riser, space out | 10.00 hrs | | |
| 03:30 Thu 25 May | R/u & test slickline, FOBV and surface lines, land & test hanger | 3.00 hrs | | |
| 06:30 Thu 25 May | Pressure up on FBIV & set packer, test tubing & annulus | 2.00 hrs | | |
| | Perform inflow test on SSSV. Slickline set & test ARH plug & prong in tubing hanger, r/d slickline | 3.00 hrs | | |
| 08:30 Thu 25 May | Unlatch THRT, POOH & stand back landing string | 8.00 hrs | | |
| 11:30 Thu 25 May | Install new AX Gasket on Basker-3 wellhead, unlatch BOP and guidelines off Basker-5, move rig over Basker-3, install guidelines, land and latch BOPs. Install debris cap on Basker-5 wellhead. | 6.00 hrs | | Shut in production Basker 2 |
| 19:30 Thu 25 May | Pressure test BOPs & casing on Basker-3 | 8.00 hrs | | |
| 01:30 Fri 26 May | Run Well Patroller to PBTD (≈ 4103m) to clean up well, circulate to inhibited brine & HiVis pills, clean up BOP and wellhead, POOH | 34.00 hrs | | |
| 09:30 Fri 26 May | Rig up Schlumberger electricline, run CBL/VDL/GR/CCL Log | 5.00 hrs | | |

| | | |
|--|--|--|
| | | |
| | | |
| | | |
| | | |
| | | |
| | | |